## Installing and configuring the Remote Agent Software

## 1. Installation

Run the 'ragent' setup programme and follow all the on screen prompts to install the software.

The installation will place two icons onto your desktop:

Remote Agent – This is used to view live/recorded footage and to copy footage off of the DVR and onto your computer.

Backup Player – Use this to play back any footage you have copied to your computer

## 2. Configuration of Remote Agent Software

Launch the Remote Agent software by double clicking on the 'Remote Agent' icon on your Desktop.



The Remote Agent Main screen will then appear. Click on the Local Setup button.

The	Local	Setup	Screen	will then a	appear.
	Local	COUMP	0010011		appour.

Local setup	×
Connect manager   Configura	IP/Domain  Port User ID  Password
	Client         DVR           Image: Client         Image: Client           Image: Client<
	System     Alarm     Video     Record       In/Out     Monitoring Audio     1     Y       Add     Modify     Defete
	OK. Cancel

Right mouse click over the 'Site' icon.

A box will appear which says 'Add group' Left mouse click on 'Add group'.

A new box will appear – type in your company name and click on 'OK'.

Local setup Connect manager Configuration		×
Group She Alert Systems Ltd	DVR Information     Name       IP/Domain     IP/Domain       Port     User ID       Password     Password       Camera Assign     Client       1     2     3       X     X     X       X     X       X	Alert Systeme Ltd 1.2.3.4 6100 User User DVR 2 2 3 2 4 X 2 8 2 4 1 Alert Systeme Ltd 1.2.3.4 6100 User DVR 2 3 2 4 4 X 2 8 2 4 1 2 5 4 Alert Systeme Ltd 1.2.3.4 6100 User PVR 2 2 3 2 4 4 X 2 8 2 4 1 2 5 4 Alert Systeme Ltd 1.2.3.4 6100 User PVR 2 2 3 2 4 4 X 2 8 2 4 1 2 5 4 Alert Systeme Ltd 1.2.3.4 6100 User PVR 2 2 3 2 4 4 5 4 1 2 2 5 3 4 4 5 5 4 Alert Systeme Ltd 1.2.3.4 6100 User PVR 2 7 3 7 4 7 8 7 8 7 8 7 8 7 7 8 7 8 7 8 7 8 7 8 7 8 7 8 7 8 7 8 7 8 7
		OK Cancel

This will create a new entry under the 'Site' icon.

Click once on your new entry (company name). This will make the following fields on the right hand side available for you to complete:

Name: Input your company name

IP/Domain: Input your IP address

Port: This will be 6100

User ID: Enter your user ID

Password: Enter your Password

Next you will need to set up the cameras and in which order you want them to appear on your screen.

Under the heading of DVR there are 16 'x' boxes, each with a drop down arrow to the right. Click on the drop down arrow and select a camera number.

There are 16 camera boxes so if you only have 4 cameras just set the top row to read 1  $\,$  2  $\,$  3  $\,$  4

Now just click on the Add button at the bottom and then click on OK.

**3. Connecting to your CCTV Cameras** On the main screen click on the following drop down arrow and select your Company name.



Click on the connect button.